


Interface "graph" between object and PicPgm





Backup





Suppression of local or remote

Class CompMaterPic-Comp		
W	Proview	1/16
02.FEB.2010.09.51		



Suppression of local or remote


Class CompMaterPic-Comp		
W	Proview	1/2
02.FEB.2010.09.51		



Suppression of local or remote

Class CompMaterPic-Comp		
W	Proview	1/3
02.FEB.2010.09.51		


Alarm and text




Suppression of local or remote

Class CompMaterPic-Comp		
W	Proview	1/4
02.FEB.2010.09.51		

Dim pushbuttons and indicators in HMI



Show manual and local in HMI



Suppression of local or remote

!!! attribute below must always placed last in this PicPgm.

Class CompMaterPic-Comp		
W	Proview	1/5
02.FEB.2010.09.51		